Application classification tables



DDIME MOVED	OPERATIONAL	SERVICE FACTORS RELATED TO NATURE OF LOAD AND PRIME MOVER			
PRIME MOVER	HOURS PER DAY	UNIFORM	MODERATE SHOCK	HEAVY SHOCK	
Electric Motor	24	1.2	1.5	2.0	
	12	1.0	1.2	1.7	
	8	0.9	1.1	1.6	
	Less than 8	0.8	1.0	1.3	
Multi-Cylinder Int. Combustion Engine	24	1.5	1.7	2.2	
	12	1.2	1.5	2.0	
	8	1.1	1.3	1.9	
	Less than 8	0.9	1.2	1.6	
Single Cylinder Int. Combustion Engine	24	1.7	2.0	2.5	
	12	1.5	1.7	2.2	
	8	1.3	1.6	2.1	
	Less than 8	1.2	1.4	1.8	

APPLICATION	NATURE OF LOAD		\D		NATURE OF LOAD		
	UNIFORM	MODERATE SHOCK	HEAVY SHOCK	APPLICATION	UNIFORM	MODERATE SHOCK	HEAVY SHOCK
AGITATORS				HOISTS			
Pure Liquids	•			Heavy Duty			•
Liquids And Solids		•		Medium Duty		•	
Liquid - Variable Density		•		Skip		•	
BLOWERS				LAUNDRY MACHINES			
Centrifugal	•			Reversing Washers		•	
Roots		•		Tumblers		•	
BREWING & DISTILLING				MILLS			
Bottling Machinery	•			Hammer			•
Can Filling Machines	•			Tumblers			•
CLAY WORKING MACHINERY				PAPER MILLS			
Brick Press			•	Bleachers	•		
Briquette Machines			•	Beater & Pulper		•	
CONVEYORS				Loghaul			•
Belt, Bucket or Chain	•			PUMPS			
Reciprocating		•		Centrifugal	•		
CRANES				Gear	•		
Main Hoists	•			Reciprocating (3 or more cyl.)		•	
CRUSHERS				Reciprocating (1 or 2 cyl.)			•
Ore and Stone			•	RUBBER & PLASTICS			
ELEVATORS				Mixing Mills			•
Escalators	•			Laboratory Equipment		•	
Freight		•		Masticator			•
FEEDERS				SCREENS			
Reciprocating			•	Rotary - Stone or Gravel		•	
Screw		•		Vibrating			•
FOOD INDUSTRY				TEXTILES			
Dough Mixer		•		Cards, Dryers, Looms		•	
Grinder		•					

NOTE: Certain applications outside those listed above may necessitate special consideration. In such cases refer to, Utkarsh. For higher speeds, couplings are required in Cast-steel only. Any couplings with Steel construction are also available on request.

USEFUL EQUATIONS

TORQUE Nm = $\frac{3000 \times KW}{3.1416 (\pi) \times RPM}$	MULTIPLY FOOT-LBS KILOGRAM-METER (Kg-m) HORSEPOWER (UK)	BY 1.3558 9.8066 0.746	TO OBTAIN NEWTON-METER (Nm) NEWTON-METER (Nm) KILOWATTS (KW)
(1)	HORSEPOWER (METRIC)	0.7355	KILOWATTS (KW)

Guide lines for selection

- 1. Service Factor: Determine service factor from application table.
- 2. Design Power: Multiply running power of driven Machinery by the service factor.
- 3. Coupling Size: Refer selection chart for your required coupling so that rating is equal or greater than design power.
- 4. If RPM is different than available in the charts then, torque should be calculated from the equation above and coupling should be selected with rated torque exceeding the calculated torque.
- 5. Bore size: Refer related coupling dimensional table to check that the required bores can be accommodated. If not select the higher size which will accommodate the shaft sizes.